



INSTALLATION INSTRUCTIONS



Water-Buddy is quick and easy to install. No tools are necessary. It's just that easy!

We recommend that you install two Water-Buddies in a typical residential application.

STEP 1: Place one system on the incoming cold water line, at least two feet after the water meter or pressure tank (if well water).

STEP 2: Place an additional system on the hot water line at least two feet after the hot water heater or boiler.

STEP 3: To install, simply affix the pair of units in opposition around the water line with the arrows pointing in the direction of water flow.

STEP 4: Thread the 4 plastic ties through the slots on the sides of the unit. Pull snug try to make it a nice, even fit, that the space between the halves is the same all around.

STEP 5: Be sure assembly is snug around the water line, but do not over-tighten. No further maintenance is required, but we suggest you visually inspect installation periodically for reliability.

You're done! You can trim excess plastic ties, but leave approximately ¼ inch protruding.

Water-Buddy begins working as soon as it is properly installed on the water line.

